


# J4 RTS

## Changing the Upper Limit



**Note:**  
If the “mushroom” stop is triggered while changing the upper limit, the motor sets the new upper limit a few millimetres below the “mushroom”.

If the new lower limit is missed in the process of changing the limit. Repeat in full, this changing limit flowchart.